



### **Step 3 Apply joint It Simple**

**Use a hard bristle or nylon stiff broom to work the product into the Joints.**

**You must soak your paving with water before you start to sweep in the product this will protect your paving and aid in getting the product deep into the joints**

**Keep the paving soaked while you work**