



Step 4 Soak It Again

When all the joints are full of product and it looks like this image then soak the paving again with water.

Allow the paving and product to dry.

Depending on the the weather conditions normally 15 to 45 minutes approximately