



## **Step 5 Final step Sweep in Joint It**

**Do this using a soft bristle brush**

**This is going to give you your final finish.**

**Sweep over the entire paved area top up joints with the product until all joints are completely full.**

**Sweep up and remove all excess product**