

WP 0907

Teak Renovator (Part 2)



2 Part System- Wessex Teak Renovator (part 2) brings the colour back to look like new teak after cleaning with Wessex Teak Cleaner (part 1).

BENEFITS

- Suitable for use on garden furniture, boat decks and other teak items
- Creates a freshly sanded look
- No hard work or bronze wool required
- Substantially reduces cleaning time
- No scrubbing or sanding (which can reduce teak thickness)
- Will not soften boat deck seams
- Removes green, food stains, fuel stains, fish blood, rust and more

DESCRIPTION

Wessex Chemical Factors' two part Teak Cleaning process includes a Teak Cleaner (part one) and a Teak Renovator (part two). Both products are suitable for use on teak boat decks, teak garden furniture, teak decking and other teak wood items.

The Wessex teak cleaning process is designed to be easy, efficient and quick to use. Compared with traditional sanding, Wessex Teak Cleaner can dramatically reduce the amount of time needed to bring old, weathered teak wood back to its original colour.

Excellent results are easily achieved with Wessex Teak Cleaner & Renovator. Our best-selling marine product that we sell worldwide. Widely considered the best product on the market – anywhere!

INSTRUCTIONS FOR USE

BADLY WEATHERED / STAINED TEAK

1. Dilute Part 1 Teak Cleaner in a bucket with fresh water at a dilution rate of 5:1 (1=Cleaner).
2. Wet teak. Remove standing water.
3. Covering teak area approximately 1m² at a time, use a clean sponge (or similar) to apply product and gently agitate. Note: For boat decks we recommend a sponge mop so you don't have to kneel.
4. Allow area to darken to a uniform dark brown.
5. Rinse thoroughly with water using a hose.
6. Repeat the process with Part 2 Teak Renovator using the same dilution rate and method.
7. After applying Part 2 Teak Renovator, the teak should lighten to a lovely uniform 'nutty' brown colour. This effect should happen almost immediately.
8. Rinse thoroughly with water.
9. Leave to dry naturally to a straw colour. A Teak Sealer can then be applied to produce a 'nutty' brown colour.

LIGHTLY WEATHERED / STAINED TEAK

1. Dilute Part 1 Teak Cleaner in a bucket with fresh water at a dilution rate of 10:1 (1=Cleaner).
2. Follow above instructions.
3. Repeat process with Part 2 Teak Renovator (10:1 dilution).

Important note: Avoid mixing Part 1 Teak Cleaner & Part 2 Teak Renovator. If mixed together both products will be neutralised and become ineffective.

PHYSICAL PROPERTIES

Physical state: Liquid

Colour: Green.

Odour: characteristic.

pH: 1

Flammability (solid, gas): Non-flammable.

PACKAGING

1 Lt

3.25 Lt

5 Lt

HEALTH & SAFETY

Danger

H314 - Causes severe skin burns and eye damage

P260 - Do not breathe spray

P264 - Wash hands, forearms and face thoroughly after handling

P280 - Wear eye protection, protective gloves, protective clothing

P301+P330+P331 - IF SWALLOWED: rinse mouth.

Do NOT induce vomiting

P303+P361+P353 - IF ON SKIN (or hair): Take off immediately all contaminated clothing.

Rinse skin with water/shower

P304+P340 - IF INHALED: Remove person to fresh air and keep comfortable for breathing

P305+P351+P338 - IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing

P310 - Immediately call a POISON

CENTER/doctor/...

P405 - Store locked up

P501 - Dispose of contents/container to hazardous or special waste collection point, in accordance with local, regional, national and/or international regulation

Hazardous ingredients: oxalic acid, C9-11 Alcohol Ethoxylate with 6.5 mol EO, hydrochloric acid ... %

Manufactured by:

Wessex Chemical Factors

9 Crane Way

Woolsbridge Industrial Park

Three Legged Cross

Wimborne

Dorset

BH21 6FA

United Kingdom

Tel: 01202 823699

Fax: 01202 813863

Email: info@wessexchemicalfactors.co.uk

Website: www.wessexboatstore.co.uk

